

ASSEMBLY INSTRUCTIONS

Frontgate® *Holiday Collection*

#146615-Deluxe Classic 2.5ft Window Swag

<u>Parts List</u>	<u>Quantity</u>	<u>Tools Required</u>
Pre-lit Classic Window Swag	1	
Hanging ribbon (tied to the back of the swag)	1	
Package of spare light bulbs and plug fuses	1	

Unpack: Carefully remove the swag from the carton, and keep the carton for future storage. Be sure to untangle any wires that may be caught (Please DO NOT forcibly remove the swag). Remove any outer wrapping.

Shape the swag:

To fully enjoy your swag and make it look its best, it may require some shaping after unpacking. Please follow the instructions below (We suggest wearing protective gloves).

- 1) Place swag on a flat surface and unfold to its full length.
- 2) With pinecones facing upward, start at the center, separate all branch tips, and move on to the end. To achieve maximum fullness, tips should not touch one another.
- 3) Repeat the process over the entire length of the swag. Upon completion, it should appear full and consistent (Some additional adjustments may need to be made to fill any remaining gaps).
- 4) Once the shaping is complete, place the swag on the desired location with ribbon held steady. Plug light cord into a power outlet, or a 5 amp or above rated extension cord. Please follow the TROUBLE SHOOTING instructions, below, if the swag fails to light.



Trouble Shooting Light Problems:

- 1) Check power – be sure that all plugs are securely connected.
- 2) Locate problem bulbs –
 - Locate any dislodged or loose bulbs and push them back into their sockets.
 - Check for any missing or broken bulbs.
- 3) Replace bulbs – use replacement bulbs supplied with your swag or a 2.5-volt replacement bulb.
- 4) Please also refer to the enclosed Safety Instructions and User Servicing Instructions for fuse/bulb replacement.

Storage:

- 1) Remove any ornaments or decorations.
- 2) Fold and smooth branch tips to assist in re-packaging.
- 3) Place in packaging and secure it. Do not store in a damp area or in an area where the temperature exceeds 100°F.

Please contact one of our Product Specialists for assembly assistance or questions at 1-800-537-8484 or e-mail to ps@frontgate.com. Specialists are available weekdays 8:00AM to 8:00PM EST or Saturdays 9:30AM to 6:00PM.